

## Latest Codes for Programming Remote to Control Other Brands of Equipment

This sheet may have additional brands and code numbers compared to the lists printed in your owner's manual. These lists are updated to include the latest information. Instructions for programming the remote to control these other brands of equipment are in the owner's manual.

### Code List for Audio Equipment

Brand	Code(s)
RCA Audio Equipment	
AM/FM	03
CD	07
Tape	06
Phono	05
Aux	04
Dimensia Audio Equipment	
AM/FM	03
CD	07
Tape	06
Phono	05
Aux	04

### Code List for Satellite Receivers

Brand	Code(s)
Chaparral	80,81
Cheyenne	81
Drake	82,83
DSS	00
General Instruments	92,93,94
RCA	00
Realistic	84
Sierra I,II,III	81
STS1	85
STS2	86
STS3	87
STS4	88
Toshiba	89
Uniden	90
Video Cipher II	91

TOCOM 15083430 CRK70, CRK71, CRK72, CRK74, CRK83, CRK84  
(Code Release 030950)

### Code List for Cable Boxes

Brand	Code(s)
ABC	22,46,53,54
Anvission	07,08
Cablestar	07,08
Diamond	56
Eagle	07,08
Eastern International	02
General Instruments	46
GI 400	04,05,15,23,24,25,30,36
Hamlin	03,12,13,34,48
Hitachi	37,43,46
Jerrold	
..04,05,15,23,24,25,30,36,45,46,47,62,65	
Macom	37,43
Magnavox	
.....07,08,19,21,26,28,29,32,33,40,41	
NSC	09
Oak	01,16,38
Oak Sigma	16
Panasonic	03,27,39,61
Phillips	
.....07,08,19,21,26,28,29,32,33,40,41	
Pioneer	18,20,44
Randtek	07,08
RCA	00,27
Regal	03,12,13
Regency	02,33
Samsung	44
Scientific Atlanta	03,22,35,63,64
Signature	46
Sprucer	27
Starcom	46
Stargate 2000	58
Sylvania	11,59
Teknika	06
Texscan	10,11,59
Tocom	17,21,49,50,55
Unika	31,32,41
Universal	51,52,60
Viewstar	
.....07,08,19,21,26,28,29,32,33,40,41	
Warner Amex	44
Zenith	14,42,57,61

CRK7411  
XX15207-170  
E1A53397436  
RXE 1 227721  
MADE IN  
MEXICO K3D

### Code List for VCRRS

Brand	Code(s)
Alwa	15
Akai	03,17,22,23,63,66
Audio Dynamics	14,16
Broksonic	10
Candle	07,09,13,44,45,46,52
Canon	08,53
Capchart	01
Citizen	07,09,13,44,45,46,52
Colorlyme	14
Craig	07,12
Curtis Mathes	
.....00,07,08,14,15,44,46,53,64,67	
Daewoo	13,45,52,76
dbx	14,16
Dimensia	00
Dynatech	15
Electrohome	27
Emerson	08,09,10,13,15,20,23,
.....27,34,41,42,47,49,57,62,65,67,68,70	
Fisher	02,12,18,19,43,48,58
Funai	15
GE	00,07,08,32,37,53
Goldstar	09,14,46,60
Harman Kardon	14
Hitachi	05,15,35,36
Instant Replay	08
JCL	08
JCPenney	
.....02,05,07,08,14,16,30,35,51,53	
JVC	02,14,16,30,46,74
Kenwood	02,14,16,30,44,46
KLH	73
Lloyd	15
Logik	31
Magnavox	08,29,53,56
Marrantz	02,08,14,16,29,30,44,46,61
Marta	09
MEI	08
Memorex	08,09,12,15
MGA	04,27
Midland	32
Minolta	05,35
Mitsubishi	04,05,27,35,40
Montgomery Ward	06
MTC	07,15
Multitech	07,15,31,32
NEC	02,14,16,30,44,46,59,61,64
Panasonic	08,53,75

Pentax	05,35,44
Pentax Research +	46
Philco	08,29,53,56
Philips	08,29
Pioneer	05,16,50
Portland	44,45,52
ProScan	00
Quartz	02
Quasar	08,53
RCA	00,05,07,08,28,35,37,54,69
Radio Shack/Realistic	
.....02,06,08,09,12,15,19,27,43,53	
Samsung	07,13,22,32,42
Sansui	16,71
Sanyo	02,12
Scott	04,13,41,49,68
Sears	02,05,09,12,18,19,35,43,48
Sharp	06,24,27,39,45
Shinton	17,26,31,55
Sony	17,26,38
Sylvania	08,15,29,53,56
Symphonic	15
Tandy	02,15
Tashiko	09
Tatung	30
Teac	15,30,69
Technics	08
Teknika	08,09,15,21
TMK	67
Toshiba	05,13,19,48,49
Television	07,09
Unitech	07
Vector Research	14,16,44
Victor	16
Video Concepts	14,16,44
Videosonic	07
Wards	
.....05,06,07,08,09,12,13,15,25,27,31,35	
Yamaha	02,14,16,30,46
Zenith	11,17,26,72

### Code List for LaserDisc Players

Brand	Code(s)
Pioneer	33,37
ProScan	33,37
RCA	33,37



**Derniere liste de codes pour la programmation de la télécommande en vue de commander d'autres marques d'appareils**

Cette feuille indique des marques et leurs codes correspondants qui peuvent ne pas figurer dans votre guide d'utilisation. Cette liste est continuellement mise à jour pour donner les derniers renseignements. Les instructions de programmation de la télécommande en vue de commander d'autres marques d'appareils se trouvent dans le guide d'utilisation.

**Codes pour appareils audio**

Marque	Code(s)
<b>Appareils audio RCA</b>	
Synthonisateur AM/FM	03
Lecteur CD	07
Magnétocassette	06
Tourne-disque	05
Auxiliaire	04
<b>Appareils audio Dimensia</b>	
Synthonisateur AM/FM	03
Lecteur CD	07
Magnétocassette	06
Tourne-disque	05
Auxiliaire	04

**Codes pour antenne parabolique**

Marque	Code(s)
Chapparral	80,81
Cheyenne	81
Drake	82,83
DSS	00
General Instruments	92,93,94
RCA	00
Realistic	84
Sierra I,II,III	81
STS1	85
STS2	86
STS3	87
STS4	88
Toshiba	89
Uniden	90
Video Cipher II	91

**Codes pour convertisseurs**

Marque	Code(s)
ABC	22,46,53,54
Anvion	07,08
Cablestar	07,08
Diamond	56
Eagle	07,08
Eastern International	02
General Instruments	46
GI 400	04,05,15,23,24,25,30,36
Hamlin	03,12,13,34,48
Hitachi	37,43,46
Jerrold	04,05,15,23,24,25,30,36,45,46,47,62,65
Magcom	37,43
Magnavox	07,08,19,21,26,28,29,32,33,40,41
NSC	09
Oak	01,16,38
Oak Sigma	16
Panasonic	03,27,39,61
Philips	07,08,19,21,26,28,29,32,33,40,41
Pioneer	18,20,44
Randtek	07,08
RCA	00,27
Regal	03,12,13
Regency	02,33
Samsung	44
Scientific Atlanta	03,22,35,63,64
Signature	46
Spucer	27
Starcom	46
Stargate 2000	58
Sylvania	11,59
Teknika	06
Texscan	10,11,59
Tomcom	17,21,49,50,55
Unika	31,32,41
Universal	51,52,60
Viewstar	07,08,19,21,26,28,29,32,33,40,41
Warner Amex	44
Zenith	14,42,57,61


**Codes pour magnétoscopes**

Marque	Code(s)
Aiwa	15
Akal	03,17,22,23,63,66
Audio Dynamics	14,16
Broksonic	10
Candle	07,09,13,44,45,46,52
Canon	08,53
Capenart	01
Citizen	07,09,13,44,45,46,52
Colortyme	14
Craig	07,12
Curtis Mathes	00,07,08,14,15,44,46,53,64,67
Daewoo	13,45,52,76
dbx	14,16
Dimensia	00
Dynatech	15
Electrohome	27
Emerson	08,09,10,13,15,20,23,27,34,41,42,47,49,57,62,65,67,68,70
Fisher	02,12,18,19,43,48,58
Funai	15
GE	00,07,08,32,37,53
Goldstar	09,14,46,60
Harman Kardon	14
Hitachi	05,15,35,36
Instant Replay	08
JCL	08
JCPenney	02,05,07,08,14,16,30,35,51,53
JVC	02,14,16,30,46,74
Kenwood	02,14,16,30,44,46
KLH	73
Lloyd	15
Logik	31
Magnavox	08,29,53,56
Marantz	02,08,14,16,29,30,44,46,61
Marta	09
MEI	08
Memorex	08,09,12,15
MGA	04,27
Midland	32
Minolta	05,35
Mitsubishi	04,05,27,35,40
Montgomery Ward	06
MTC	07,15
Multitech	07,15,31,32
NEC	02,14,16,30,44,46,59,61,64
Panasonic	08,53,75

Pentax	05,35,44
Pentax Research +	46
Philco	08,29,53,56
Philips	08,29
Pioneer	05,16,50
Portland	44,45,52
ProScan	00
Quartz	02
Quasar	08,53
RCA	00,05,07,08,28,35,37,54,69
Radio Shack/Realistic	02,06,08,09,12,15,19,27,43,53
Samsung	07,13,22,32,42
Sansui	16,71
Sanyo	02,12
Scott	04,13,41,49,68
Sears	02,05,09,12,18,19,35,43,48
Sharp	06,24,27,39,45
Shinton	17,26,31,55
Sony	17,26,38
Sylvania	08,15,29,53,56
Symphonic	15
Tandy	02,15
Tashiko	09
Tatung	30
Teac	15,30,69
Technics	08
Teknika	08,09,15,21
TMK	67
Toshiba	05,13,19,48,49
Totevision	07,09
Unitech	07
Vector Research	14,16,44
Victor	16
Video Concepts	14,16,44
Videosonic	07
Wards	05,06,07,08,09,12,13,15,25,27,31,35
Yamaha	02,14,16,30,46
Zenith	11,17,26,72

**Codes pour lecture laser**

Pioneer	33,37
ProScan	33,37
RCA	33,37
TOCOM 15083430	
CRK70, CRK71, CRK72,	
CRK74, CRK83, CRK84	
(Code Release 030950)	



PROSCAN

RCA



**SPS 4434-1**

For CRK74 Remotes

This replacement Remote does not have several functions which were present on the original (CRK 45 series S/N 177994). In most instances they are for older RCA models, such as Dimensia Audio. If such applications and/or VCR tracking are necessary then please reorder S/N 197944.

If your replacement remote fails to function correctly right out of the box use the following instructions to program it. The functionality will be the same as the original.

### Programming Steps:

1. Press and hold the device button.
2. While holding the device button, enter the 2-digit code number from the list of brands.
3. Release all buttons and try operating the device.

Accessories & Components  
Business  
2000 Clements Bridge Road  
Deptford, NJ 08096-2088

 **THOMSON CONSUMER ELECTRONICS**

